



CON RESPALDO 480mm / WITH BACKREST 480mm		
Peso / Weight		395 Kg
Material / Material	Longitud / Length	Acabado / Finish
Hormig n / Concrete	480mm	Decapado /Erido visto / Stripping finish
SIN RESPALDO 480mm / WITHOUT BACKREST 480mm		
Peso / Weight		195 Kg
Material / Material	Longitud / Length	Acabado / Finish
Hormig n / Concrete	480mm	Decapado /Erido visto / Stripping finish
CON RESPALDO 1500mm / WITH BACKREST 1500mm		
Peso / Weight		1245 Kg
Material / Material	Longitud / Length	Acabado / Finish
Hormig n / Concrete	1500mm	Decapado /Erido visto / Stripping finish
SIN RESPALDO 1500mm / WITHOUT BACKREST 1500mm		
Peso / Weight		625 Kg
Material / Material	Longitud / Length	Acabado / Finish
Hormig n / Concrete	1500mm	Decapado /Erido visto / Stripping finish
RESPALDO 1500mm / BACKREST 1500mm		
Peso / Weight		915 Kg
Material / Material	Longitud / Length	Acabado / Finish
Hormig n / Concrete	1500mm	Decapado /Erido visto / Stripping finish

SUMINISTRO SUPPLY LIST




x1

x2 Pernos M20x180
M20x180 steel bolts




x1

x2 Pernos M20x180
M20x180 steel bolts




x1

x2 Pernos M20x180
M20x180 steel bolts




x1

x2 Pernos M20x180
M20x180 steel bolts




x1

x2 Pernos M20x180
M20x180 steel bolts







SANTA & COLE

Bancos 108
Enric Batlle
Joan Roig







INSTRUCCIONES DE MONTAJE ASSEMBLY INSTRUCTIONS

Instalación bancos 480mm
480mm benches assembly



Instalación bancos 1500mm
1500mm benches assembly



Rellenar los taladros de resina epoxi, Portland rápido o similar.
Fill the drills with epoxy resin, fast-drying cement or such.

Rellenar los taladros de resina epoxi, Portland rápido o similar.
Fill the drills it with epoxy resin, fast-drying cement or such.